

Low-emission carpentry: what to check before ordering cabinets

By [DirectHome Editorial](#)

Updated 14 September 2026

6 min read

[Explore our carpentry & built-ins service ↗](#)


Some cabinet boards and adhesives can [release formaldehyde into indoor air](#). Choosing materials with lower emissions is one way to reduce that source in a newly renovated home. Before ordering, ask which boards, adhesives and finishes will be used and which test reports or certification support the claim for those products.

For a whole-house [carpentry and built-in fit-out](#), agree the materials while they can still be selected, and discuss ventilation before the household moves back in. A report for one board does not describe every part of a cabinet or measure the air in a finished room. The following checks help you understand what the supplier's claim actually covers.


Find out which cabinet materials the claim covers

Different components, different claim scopes

Surface



Board



Adhesive



Check what each report actually covers

A claim about one board does not automatically cover every cabinet material.


Ask the supplier to explain the phrase in the quotation. Does it refer to a particular panel, the adhesive, a decorative surface, the assembled cabinet or an indoor-air measurement after installation? Those are different subjects. A test performed on one panel cannot automatically stand in for a claim about the whole room.

Singapore's [formaldehyde controls for interior paint](#) do not certify the boards and adhesives inside a cabinet. Ask for reports or certification that apply to those materials. A broad statement such as "compliant materials" leaves you unable to tell what was tested.

Once you have chosen the materials, put their product names and references in the order so the fabricator can supply what you selected. You do not need to become a laboratory specialist: start by checking that each report names the same product as the quotation. If it does not, ask for the matching report before accepting the claim.

List the boards, finishes and adhesives in the cabinets

Which part does the claim describe?



Match each claim to its material.

A report for one component does not describe the entire room.

The visible face is one part of the assembly. The product schedule defines what each supporting document can substantiate.

List the supporting panels, door and exposed finishes, backing, edge treatment and adhesives relevant to the proposed work. The list should be understandable enough to connect a product reference with a physical part of the cabinet. Ask the fabricator to identify any component that remains undecided.

The decorative surface and its supporting substrate are separate choices. This matters when a quotation gives a surface brand prominently but leaves the panel underneath generic. Ask for the actual board reference rather than assuming the most visible name explains the concealed material.

You may decide that some components need different evidence or selection criteria. Make that distinction explicit. For instance, moisture suitability and emissions are separate questions: a claim about one does not by itself settle the other. A wardrobe still has to suit its room, dimensions and intended use as well as the agreed material requirements.

Check that the emission report names the board you are buying

A document-reading framework. Ask the supplier or qualified testing professional to interpret technical differences.

Document question	Useful answer	What remains unresolved otherwise
What was tested?	A named sample linked to the specified product	Whether the order and report describe the same material
Which characteristic?	The measured emission or other stated property	Whether the evidence supports the advertised claim
Under what method?	The applicable method and assessment basis	Whether results can be compared meaningfully
Who issued it?	Identifiable laboratory or certification body and relevant scope	Whether the document can be verified
What will be supplied?	The same specified product or an approved documented change	Whether the evidence follows through to fabrication

For furniture containing composite wood panels, NEA recommends requesting panel formaldehyde-emission reports from appropriately accredited laboratories. Ask the supplier for the complete relevant report or a clear verifiable reference, not only a cropped result detached from its sample description.

Match the manufacturer, product identification, panel description and tested characteristic with the proposed item. Record the test method, report date and the basis for the pass or classification being claimed. Where a supplier offers a different thickness or product variant, ask it to explain how the evidence applies rather than making that extension yourself.

Be cautious about comparing two numbers when the methods or samples differ. A lower figure is only a useful comparison if the basis is comparable. Ask the supplier to state the reason for the classification in plain language, and seek competent technical interpretation where a material choice depends on a distinction you cannot resolve.


Check which product the certificate covers

Quoted product	Certificate entry
Exact reference	Matching scope
Check the same product is named	
Check that the certificate covers the exact product in the quotation.	

Where a certification or label is offered, check the exact product entry, issuer, validity and scope. Keep the reference beside the product schedule so it can be checked again if the material changes. Certification of one product family should not become an unqualified endorsement of everything the workshop supplies.

A supplier that provides a clear schedule and traceable evidence makes the choice easier to assess. A missing document does not by itself establish that the material is harmful; it means the claimed attribute has not been substantiated for your purchase. Keep that distinction when deciding whether to seek more information or choose another documented option.

Make sure the agreed materials are used



Name the agreed material references in the quotation or accompanying specification and record how substitutions are approved. Availability can change, and similar-looking panels can be offered as alternatives. Require the replacement's evidence and suitability to be reviewed before it is treated as equivalent.

Agree what reasonable delivery or fabrication records will identify the materials used, such as supplier references, labelled packaging or a material confirmation tied to the cabinet schedule. Avoid demanding a photograph of every offcut without knowing what it would prove. The evidence should connect the agreed specification to the work being supplied.


Keep the final schedule at handover. It can help with later repairs, matching finishes and questions about the installed materials. If a component was changed with approval, retain the revised reference so the record describes the cabinet actually in the house.

Record the proposed materials and specifications in the quotation so substitutions can be checked.

Comparing built-in wardrobe quotes: what a per-foot rate leaves out →


A board report does not measure the air in your finished room

Product evidence and room evidence



Board emission report

Describes a named product under its test method.



Indoor-air assessment

Describes the space and test conditions.

Board emission report: Describes a named product under its test method. Indoor-air assessment: Describes the space and test conditions. Schematic only; no dimensions or site-specific approval are implied.

A panel report answers a product question. Indoor-air testing answers a different question about the conditions of the space at the time and under the method used. If the household needs the latter assessed, agree the scope with a competent testing provider rather than treating a material certificate as a room measurement.

NEA also advises [planning ventilation with the contractor and allowing it in the renovation programme](#). The materials, room conditions and occupancy decision need to be considered together; a low-emission claim is not a promise that every newly renovated space is immediately ready for occupation.

Use the [carpentry buying guide](#) to review the rest of the cabinet design and quotation. Before ordering, bring the proposed material list and its supporting reports to the discussion, and agree how any substitution will be checked. Keep the ventilation plan alongside that choice: selecting lower-emission materials is one part of preparing the renovated home for use.

More on carpentry & built-ins

Article [Comparing built-in wardrobe quotes: what a per-foot rate leaves out](#)

Article [Sliding or hinged wardrobe doors? Test access to what is inside](#)

Article [Under-Stair Storage Solutions for Singapore Landed Homes](#)

Our service

Carpentry & Built-Ins for your home

Explore the service, then discuss what your home needs with our team.

[View service details ↗](#)

Still weighing your options?

Plan with the buying guide

Bring the choices, costs and questions together before deciding what to do next.

[Read the carpentry & built-ins buying guide →](#)

[More carpentry & built-ins articles →](#)

Ready to discuss your home? [WhatsApp our team](#) or [request a quote](#).