

A step-free shower still needs a sloping floor

By [DirectHome Editorial](#)

Updated 14 September 2026

5 min read


[Explore our bathroom renovation service](#) ↗

A step-free shower has an entrance without a kerb, but its floor still needs to slope towards the drain. There must also be room beneath the finish for the drain, its connection and the waterproofing. Removing a kerb alone does not settle those details or show how water will be contained during use.

In a [landed bathroom renovation](#), the existing floor and drain position can limit the layouts that will work. The team needs to show the shower floor alongside the bathroom and adjoining bedroom levels before the screen or tiles are ordered. That is how you check whether the desired entrance can be built within the space available.

A flush entry and a draining floor are different requirements

Step-free entry does not mean flat floor



Schematic only. The floor build-up and structure must be assessed.


A flush entry can coexist with a sloping shower floor. This section contains no installation dimensions and does not authorise recessing the structure.

Step-free describes the transition a person crosses at the shower entrance. It does not mean the shower floor is flat in every direction. The water still needs a designed path towards drainage, with the screen, shower position and surrounding wet-area details working together.

The components of a curbless shower system illustrate that relationship: slope, drain, waterproofing and the available floor build-up are coordinated as an assembly. That manufacturer example does not set the permitted detail for every Singapore bathroom. It shows why a floor section is more informative than a photograph of a seamless finish.

Ask to see the finished levels at the bathroom door, the shower entrance and the drain, with the materials between them. If the proposal depends on raising the whole bathroom floor or lowering part of the existing construction, follow that change to the adjoining room and door. An easy shower entry should not be achieved by silently creating an awkward new threshold elsewhere.

Check the space below the finished floor for the drain and its connection




The installer needs space for the selected drain and its connection as well as the layers of the floor. Record what is known about the existing slab and plumbing, and what must be investigated. A tiled surface conceals that information; measuring the visible room alone does not establish it.

Where a recessed construction is proposed, ask the appropriate professional to confirm whether and how it can be achieved. The [manufacturer's curbless guidance](#) ties recessing to structural suitability. Do not treat cutting into a retained concrete slab as an ordinary floor-finishing adjustment.

If the original idea cannot fit the available construction, compare the actual alternatives with the team. A different shower position, drain arrangement or floor build-up may be worth considering. Keep the intended access benefit in view while evaluating the effect on the rest of the bathroom, rather than preserving one visual reference at any cost.

Follow shower spray and runoff towards the drain

Keep the water route beside the movement



Spray and runoff

Trace the shower's water towards its drain.

Entry and use

Review the person's route separately from water.

Spray and runoff: Trace the shower's water towards its drain. Entry and use: Review the person's route separately from water. Schematic only; no dimensions or site-specific approval are implied.

Show the shower head, intended user position, screen and opening on the plan. Ask where spray and runoff are expected to go while the shower is being used and when the screen opens. A drain shown neatly at one edge does not by itself establish that all water reaches it.

Have the installer explain how the selected drain and discharge arrangement relate to the proposed shower equipment. This is a system-selection question, with the actual product information and site route supplied by the professionals. [Regulated sanitary plumbing work](#) requires a Licensed Plumber.

Review cleaning access at the same time. Can the drain cover and any serviceable parts be reached as intended after the screen and cabinetry are installed? The household should understand the normal care required for the chosen drain, and the installer should explain which work needs professional attention. A discreet drain is useful only if its upkeep remains practical.

Design the movement for the person who will use it

The design succeeds at the junctions between these decisions.

Interface	Decision to resolve	Evidence to bring together
Bathroom to shower	Entry level and the intended crossing	Finished-level section and user requirements
Shower to drain	Falls, drain arrangement and water route	Selected system details and plumbing review
Floor to structure	Available build-up and any proposed recess	Site information and appropriate professional assessment
Screen to user	Opening, movement and assistance space	Screen drawing and actual equipment dimensions
Waterproofing to adjoining work	Continuity at edges, outlets and penetrations	Approved system detail and inspection records

Removing a step can address one difficulty while leaving others untouched. The shower opening, door movement, standing or seated position, controls and any assistance space must suit the intended person. Check the route from the bedroom or bathroom door as well as the shower entrance itself.


Where care or mobility needs are involved, obtain [individual advice from an occupational therapist or healthcare professional](#). A showroom arrangement cannot establish that a particular transfer or assistance task will work. Give the design team the relevant assessed needs so the construction and fittings can support them.

Review the screen in its open position and place the proposed seat or other equipment at its actual size. A panel may contain spray effectively but reduce access in a way that matters to the user. If the person will be helped, include where the helper stands and how they enter and leave without relying on a generic clearance pulled from an unrelated example.

Plan the waterproofing checks alongside the level and drainage checks before tiling. [Bathroom waterproofing: how to prevent leaks after renovation →](#)

Keep the waterproofing continuous through the change

Waterproofing continues through the change



Detail the junction before the tile

Keep the waterproof layer continuous across the changed junctions and drain arrangement.

A step-free detail still needs an explicit waterproofing design. Ask where the waterproofed area extends, how it connects to the drain and how junctions or penetrations are treated. The chosen system should determine the details and the sequence, rather than allowing the tile pattern to decide where protection stops.

Before concealment, agree the inspection and test evidence appropriate to the selected system. A liquid membrane has its own preparation, curing and protection conditions; another assembly may require different work. A photograph of a coloured coating is not the complete record of its suitability or performance.

The landed bathroom buying guide covers the wider renovation. Bring the existing floor and drain information, chosen shower equipment and the intended user's needs. Ask for a side-view drawing showing the finished levels, then review how the person enters and how water reaches the drain. Both need to work in the same layout.

More on bathroom renovation

Article [Leak below a bathroom: where could the water be coming from?](#)

Article [Bathroom waterproofing: how to prevent leaks after renovation](#)

Our service

Bathroom Renovation for your home

Explore the service, then discuss what your home needs with our team.

[View service details ↗](#)

Still weighing your options?

Plan with the buying guide

Bring the choices, costs and questions together before deciding what to do next.

[Read the bathroom renovation buying guide →](#)

[More bathroom renovation articles →](#)

Ready to discuss your home? [WhatsApp our team](#) or [request a quote](#).